



Thank you for purchasing a **Zia Drive** pedal. The Zia Drive was designed with the rhythm guitar player in mind. The voicing of the Zia Drive is very tight with minimal compression put into your signal chain. Complex chord voicings will cut right through with your Zia Drive.

The Controls of the Zia Drive are very straight-forward.

LEVEL CONTROL

The Level control is a master volume output for the Zia Drive. This control limits the signal coming out of the Zia Drive.

GAIN CONTROL

The Gain control will control the amplification level of the Zia Drive. This control will allow you more or less of an overdriven sound. Turned all the way clockwise will get you the greatest amount of gain. Set the Gain at 9:00 and you will have a clean boost.

TONE CONTROL

The Tone control will allow you to color your sound brighter or darker. With your Tone control in the 12:00 position the tone is at unity. Turning the knob clockwise will add brightness to your sound, counter-clockwise will add darkness to your sound.

INPUT/OUTPUT

The Input jack is located on the right side of the Zia Drive when looking at your pedals faceplate. When you plug a cable into the Input jack, the 9 Volt battery inside will be activated. If you are not using an external power supply, when the pedal is not in use it is best to unplug cable from the Input jack in order to save battery life. The Output jack is located on the left side of the pedal.

POWER SUPPLY

The Zia Drive uses a standard style 9 Volt negative tip DC power supply. *Use of incorrect power supply will cause permanent damage to pedal and void the warranty.* When a power supply is used, the battery is bypassed.

WARRANTY

Guaranteed to original purchaser for the period of Two Years. Any negligent use of pedal will void the warranty.